



Installing I-Beam Post Guide P/N 27635

1. Choose correct size bolt for your frame and place bolt through both sides of clip. Use 1 washer under head of bolt and 1 before nut.
2. Hold tube in place on I-Beam. Set clip assembly over tube.
3. Slip clip ears over I-Beam and hand snug.
(May tap with wrench to get clip on rail)
4. Tighten bolt slightly
5. Locate in proper position and tighten bolt to set.



Clamp on top rail



Clamp on bottom rail



TOOLS REQUIRED = (2) 9/16" Wrenches

PARTS INCLUDED P/N 27635 – 75"

- 2 - P/N 27651PG 90° Pre-galvanized tube
- 2 - P/N 11377 PVC tube, 74" white
- 1 - P/N 11471 Hardware Carton
- 4 - P/N 27681G Clamp, I-Beam, Galv.
- 2 - P/N 11331 Cap, PVC, White
- 2 - P/N 11023 Hex Head Cap Screw, 3/8-16 x 1-1/2"
- 2 - P/N 11044 Hex Head Cap Screw, 3/8-16 x 2-3/4"
- 4 - P/N10960 Washer, USS Flat, 3/8"
- 2 - P/N 10810 Locknut, 3/8-16
- 1 - P/N 00580 Instruction Sheet



On I-Beam boat trailer



On I-Beam boat lift